


SINGLE PHASE CIRCUIT BREAKER FOR TENANT MAINS - SEE TABLE FOR SIZE
100AMP SERVICE FUSE HOLDERS
SINGLE PHASE ELECTRIC METERS BY OTHERS
NEUTRAL LINK
POLE FILLER
125AMP 3 PHASE METER PANEL ISOLATOR / MAIN SWITCH



APARTME	NT NUMBERS / OUTGOING CIRCUIT BREAKERS
1	63AMP 6kA Circuit Breaker - Single Phase
2	63AMP 6kA Circuit Breaker - Single Phase
3	63AMP 6kA Circuit Breaker - Single Phase
4	63AMP 6kA Circuit Breaker - Single Phase
5	63AMP 6kA Circuit Breaker - Single Phase
6	63AMP 6kA Circuit Breaker - Single Phase
7	63AMP 6kA Circuit Breaker - Single Phase
8	63AMP 6kA Circuit Breaker - Single Phase
9	63AMP 6kA Circuit Breaker - Single Phase

## \* ALL INCOMING CONTROL / OUTGOING CONTROL BREAKERS CAN BE CHANGED TO SUIT CUSTOMERS NEEDS \*

SHEET	1 of 1	SCALE NTS	REV	A	PROJECT
SIZE A3  DRAWN RN on 10/10/2017					MP-9W+ISO
CHECK	SV				METER PANEL NUMBER MP 2
APPR.					METERPANELS PTY LTD
					19 ALEX AVE, MOORABBIN, VIC 3189 PH: (03) 9555 9699